



#### NEW WORK KEYED NOTES

- 1 NEW CASEWORK
- 2 INSTALL WALL OUTLETS
- 3 INSTALL SUPPLY AND RETURN AIR IN NEW OFFICE
- 4 ALIGN NEW WALL WITH COLUMN
- 5 NEW WALL AND DOOR. FULL LIGHT DOOR RELOCATED FROM ROOM 228.
- 6 EXTEND WALL TO 10'-0".
- 7 EXISTING CASEWORK TO BE PAINTED.
- 8 NEW GYPSUM BOARD PARTITION TO BE PAINTED.
- 9 EXISTING TILE FLOOR TO REMAIN.
- 10 ADD VENTILATION FOR SERVER.
- 11 REPAIR WALLS AND INSTALL WALL COVERING.
- 12 REPAIR WALLS AND PAINT.
- 13 PAINT CEILING.
- 14 ADD LIGHT FIXTURE(S) TO ROOM.
- 15 INSTALL COVER PLATES AT ABANDONED IT OUTLETS. COVER PLATES TO BE BROWN TO MATCH WOOD WALL.

**OFFICE SPACE AT  
7625 N. UNIVERSITY, PEORIA, IL**

**NEW WORK FLOOR PLAN**  
1/8" = 1'-0"

**NEW WORK FLOOR PLAN**  
01/20/10